

EASY LOCKS

Mounting tips



First of all: Don't screw the white plastic washers to your board. They're just spacers for transportation, so you can separate the magnets from each other. Once you've separated the magnets, the spacers can be binned.

To place your EASY LOCKS in the correct position, please download the mounting template from our website (https://dev.bluguitar.com/media/pdf/c2/bc/db/bluguitar-amp1_stencil.pdf or scan the QR code below) and print it. Make sure your printer doesn't resize the PDF while printing. The scaling must be at 100%.

Don't tighten the screws too much. If the EASY LOCKS can move just a little bit, they can adapt to the exact position of the AMP1™.

Use the metal washers only if needed. It depends on the material of your board if you need them or not. If the bottom of your board is revetted with e.g. Velcro, we recommend using the washers. Just give it a try!

If you want to screw your EASY LOCKS onto a metal pedal board (Pedaltrain® or similar), you can use the included wood screws. Please drill a 2.5 mm to 3 mm hole with a metal drill first.

